



Nova Operating Instructions

Once the relevant button on the entrance panel has been pressed, the Nova monitor will give an audible call tone.

The picture will appear on the monitor automatically. For audio communication press the audio speech button - this button must be pressed to speak and released to hear the visitor at the entrance panel.

Once communication has been made select button to release the lock. The monitor will deactivate automatically.



Brightness control button

- Aux 1: -Button for auxiliary services as required
- Aux 2: -Button for auxiliary services as required



Contrast control button



Button to bring monitor live and manual sequencing of any additional entry panel or monitor.



Door lock release button



Audio speech button- this button must be pressed to speak and released to hear the visitor at the entrance panel